

NOTICE

- *Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item.Refer to part list and hardware list below for guidance.
- *This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- *This item may require periodic tightening.
- *If you are having difficulty,our friendly Customer Care team is always here to help.Please email customersupport@safavieh.com

PREPARATION

- *Before beginning assembly of product,make sure all parts are present.Compare parts with part contents list and hardware contents list.
- *If any part is missing or damaged,do not attempt to assemble the product.
- *Estimated Assembly Time: 10 minutes.
- *Tools Required for Assembly(included):Allen Key

CARE AND MAINTENANCE

- *Clean with a dry cloth or slight dampened in pure water if necessary.
- *Avoid hard rubbing when cleaning.
- *Vacuum the seat platforms to remove dust.
- *Will fade naturally, over time, in sunlight.

Part List and Hardware List


PIECE	DESCRIPTION	PICTURE	QUANTITY
A	SEAT		1
B	legs		4
C	Adjustable middle leg		1
HW1	Socket Screws 6x20mm		16
HW2	Split Lock Washer 6mm		16
HW3	Flat Washer 6mm		16
HW4	Rubber Washer 6mm		16
HW5	Allen key 4mm		1

SAFAVIEH

C O U T U R E

SFV8901

Product Dimensions: 96.8"W x 44"D x 29.5"H



Weight Capacity: 750 lbs
Warning:Do not stand on sofa
Warning:Do not over torque bolts.

PREPARATION


*Before beginning assembly of product,make sure all parts are present.Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged,do not attempt to assemble the product.

*Estimated Assembly Time:10 minutes.


*Tools Required for Assembly(included):Allen Key

*If you are having difficulty,our friendly Customer Care team is always here to help.Please **email customersupport@safavieh.com**



Step 1 :

Assemble the leg(B) to seat(A) with Socket Screws(HW1) and Split Lock Washer(HW2) and Flat Washer(HW3) by use of Allen key (HW4) as shown in drawing.



Step 2 :

The adjustable middle leg is located underneath the sofa. Remove it and screw it into the sofa. Adjust it as needed as shown in the picture